

Frequenztabelle PMR 446



Gerätetyp / type d'appareil				3M PELTOR		KENWOOD			HYTERA		MOTOROLA			VERTEX	
				Lite-Com		TK3101	TK3201	TK3301 TK3501 TK3401 TK3601 TK3701	TC320 TC446 TC446S	TLKR Talkabout	XT420/460 XTNi Swiss XTN Swiss	VX-241 Swiss VX-351 Swiss			
Kanal / Fréquence Canal / fréquence		Tonfilter ton squelch		Kanal canal	Sub Kanal canal	Position Kanalschalter Commutateur canaux			Position Kanalschalter Commutateur canaux	Kanal canal	Tonfilter ton squelch	Position Kanalschalter Commutateur canaux	Position Kanalschalter Commutateur canaux		
Nr.	MHz	Nr.	Hz/Code			Nr.	Nr.	Nr.							
1	446.00625	10	94.8	1	10	1	1	1	1	1	10	1	1		
2	446.01875	18	123.0	2	18	6	6	6	2	2	18	2	2		
3	446.03125	13	103.5	3	13	3	3	3	3	3	13	3	3		
4	446.04375	17	118.8	4	17	5	5	5	4	4	17	4	4		
5	446.05625	7	85.4	5	07	8	8	8	5	5	7	5	5		
6	446.06875	5	97.7	6	05	4	4	4	6	6	5	6	6		
7	446.08125	19	127.3	7	19	7	7	7	7	7	19	7	7		
8	446.09375	8	88.5	8	08	2	2	2	8	8	8	8	8		
													Kanal canal Pos.	Sub Kanal canal	
1	446.00625	14	107.2	1	14	9	9	9	9	9	14	9	9	D152	
2	446.01875	62	D155			14	14	14	10	10	62	14	10	D155	
3	446.03125	16	114.8	3	16	11	11	11	11	11	16	11	11	D156	
4	446.04375	58	D132			13	13	13	12	12	58	13	12	D162	
5	446.05625	59	D134			15	15	15	13	13	59	15	13	D165	
6	446.06875	6	82.5	6	6	12	12	12	14	14	6	12	14	D205	
7	446.08125	71	D243			16	16	16	15	15	71	16	15	D212	
8	446.09375	15	110.9	8	15		10	10	16	16	15	10	16	D223	